

Machine Learning is a Subset of Artificial Intelligence

Al means many things to many people

Artificial Intelligence

Machine Learning

Perception & Vision


Natural Language Processing

Knowledge Representation

Planning & Navigation

Generalized Intelligence


ML itself has a lot of depth





Why Artificial Intelligence(AI) Exploding Now

Availability of increased data sourced at the edge with ubiquitous powerful compute!



Data

2016 – 1 zettabyte



IP Traffic

2020 – 2.3 zettabyte









Al Presents Significant Opportunity for Innovation

VR/MR



IoT



Robotics



Home, surveillance & analytics



Drones



Automotive



Shipping & logistics



Mobile





Distributing Intelligence

Cloud-based training

High-performance processing



On-device learning

Security and privacy for your data



Al in your hand & cloud

Real-time inference for autonomous systems





Why is On-device ML Driving AI to the Edge?











Arm ML Platform Enables










Arm's ML Computing Platform





Components of Arm ML Platform


Software



Specialized Acceleration



Hardware









Arm Compute Library

Faster, advanced processing

What is the Arm Compute Library?

Functions for CV and deeplearning algorithms

Optimized for Arm CPU and GPU

OS and platform agnostic

No fee, MIT license

Delivers faster processing

4.6x faster than stock OpenCV on NEON

Offers OpenCV and Open VX compatibility

Use as a plug-in backend for your own runtime implementation

Available now: https://developer.arm.com/technologies/compute-library



Arm Compute Library Partners










Computer Vision (CV)



Spirit for Object Detection and Localization





Comparison with Neural Network Framework Solutions









Spirit: Key Features

Object localization (>200k locations in full HD)

Size variation (~20x for full HD)

Scalable to 4K without performance compromise

Real time, 60 fps, no dropped frames

Invariance to optical distortions

Invariance to illumination conditions

High occlusion tolerance

Suitable for stationary and moving cameras





Comparison with a DSP

Spirit uses a form of HOG*/ SVM* baked into an efficient hardware design

Using a DSP to achieve the same performance

E.g. Pedestrian Detection on a DSP

- Processed at VGA resolution
- Achieving 5fps
- Operating at 40MHz/50MHz
- Scaling this to Spirit performance levels of 1080p60 would require the DSP to run at 3.24GHz






ML on Mali GPUs



Mali GPUs: Increasing ML Throughput and Efficiency



- GEMM depicts core functionality of ML algorithms
- Mali-G72 has several optimizations to improve ML inference
 - Less power-hungry FMA unit
 - Bigger L1 cache in the execution engine
- Mali-G72 is the most efficient Mali GPU for machine learning







Al Applications at the Edge on Arm





Detect plant diseases

Sort cucumbers

Detect Caltrain delays



Instruction Sets for Al

Cortex-A

- Additional dot product instructions (Cortex-A55 and Cortex-A75)
- New Scalable Vector Extensions (SVE) instructions

Cortex-M

 Optimized CMSIS-DSP libraries for matrix multiplication

Closely-coupled acceleration

- Improved performance and efficiency (for broader use cases)
- Flexibility in multi-core computing with Arm DynamIQ technology



DynamIQ: New Cluster Design for New Cores

Arm DynamIQ big.LITTLE systems:

- Greater product differentiation and scalability
- Improved energy efficiency and performance
- SW compatibility with Energy Aware Scheduling (EAS)


Private L2 and shared L3 caches

- Local cache close to processors
- L3 cache shared between all cores

DynamIQ Shared Unit (DSU)

Contains L3, Snoop Control Unit (SCU) and all cluster interfaces

Additional instructions for ML



New DynamIQ-based CPUs for New Possibilities

Cortex-A75 processor

>50%

more performance compared to current devices



Estimated device performance using SPECINT2006, final device results may vary Comparison using Cortex-A73 at 2.4GHz vs Cortex-A75 at 3GHz

Cortex-A55 processor

2.5x

higher power efficiency compared to current devices




Comparison using Cortex-A53 in 28nm devices vs Cortex-A55 in 16nm devices




Enhanced Architecture for Emerging Use Cases

Computer Vision





Machine Learning








Introducing the Scalable Vector Extension (SVE)













Instruction Sets for Al

Cortex-A

- Additional dot product instructions (Cortex-A55 and Cortex-A75)
- New SVE instructions

Cortex-M

 Optimized CMSIS-DSP libraries for matrix multiplication

Closely-coupled acceleration

- Improved performance and efficiency (for broader use cases)
- Flexibility in multi-core computing with DynamIQ technology



Software Optimizations: Cortex-M Example

Convolution


- Use of partial im2col to reduce the memory footprint
- Optimized data dimension layout (Height-Width-Channel) to save im2col overhead

Pooling

- Split into x-pooling and y-pooling instead of window-based
- 5.1X improvements compared to Caffe-like implementation

Activation

- ReLU: use SIMD within a register, 2.6X improvement compared to Caffe-like implementation
- Sigmoid and Tanh: use table look-up



*Baseline uses CMSIS 1D Conv and Caffe-like Pooling/ReLU

The new kernels will be integrated into future versions of CMSIS



Instruction sets for Al

Cortex-A

- Additional dot product instructions (Cortex-A55 and Cortex-A75)
- New SVE instructions

Cortex-M


 Optimized CMSIS-DSP libraries for matrix multiplication


Closely-coupled acceleration

- Improved performance and efficiency (for broader use cases)
- Flexibility in multi-core computing with DynamIQ technology




Interface to Acceleration Logic







Flexible Acceleration Platform





Arm ML Platform Enables









Thank You! Danke! Merci! 謝謝! ありがとう! **Gracias!** Kiitos!





The Arm trademarks featured in this presentation are registered trademarks or trademarks of Arm Limited (or its subsidiaries) in the US and/or elsewhere. All rights reserved. All other marks featured may be trademarks of their respective owners.

www.arm.com/company/policies/trademarks